


* TOLERANCES STD. +/- 0.1 INCHES [+/- 3 MM]
 * ALL DIMENSIONS IN INCHES [MM]

* SECONDARY FUSE CLIPS ARE SUPPLIED LOOSE WITH TRANSFORMER
 * PRIMARY FUSE CLIPS ARE OPTIONAL
 * PRIMARY AND SECONDARY FINGER GUARD ARE OPTIONAL



NOTES:





TITLE: HPS IMPERATOR
 1 PHASE INDUSTRIAL CONTROL TRANSFORMER
 600V-120V/240V

DES:	WWONG
DATE:	07/06/15
SCALE:	NTS

SHEET 1 OF 2

EDBPH150AJ



TITLE: HPS IMPERATOR
CONNECTION INFORMATION
600V-120V/240V

NO.	DATE	BY	REVISION

DES:	WWONG
DATE:	07/06/15
SCALE:	NTS

SHEET 2 OF 2

EDBPH150AJ